



Electronic lock

SELO-B₂

SELO-BF₂

SELO-BFE₂

1. Generally

Thank you for deciding for a safe with the SECU Sicherheitsprodukte SELO-B₂, SELO-BF₂ or SELO-BFE₂. You have acquired a product meeting extremely high security requirements and developed and manufactured using the latest technical potential. Please read the entire User Manual before programming and store it at a safe place for future reference.

The electronics is available in a version with a fingerprint unit SELO-BF₂/SELO-BFE₂ and in another version without the fingerprint unit SELO-B₂.

The present user manual applies to both versions, however, the menu structure is able to detect automatically the appropriate version and thus only the menu items intended for it are active. The items relevant only for the electronics with a fingerprint unit are marked with *.

Generally, you can open the safe in three possible ways:

- with a code (SELO-B₂, SELO-BF₂ and SELO-BFE₂)
- with an E-Key (SELO-B₂, SELO-BF₂ and SELO-BFE₂, ident medium E-Key not included in the delivery)
- with your fingerprint (SELO-BF₂ and SELO-BFE₂)*

The administrator code when **delivered from the factory is 123456**. This code must be changed. Additional 9 users with a code to be entered by the keyboard can be defined. Such code has always six digits, similarly to administrator's code.

Additionally, up to 250 E-Keys for contactless opening can be stored.

In case you possess a safe with a fingerprint unit, up to 20 users with fingerprint can be additionally stored. Users with fingerprint are identified in the user list of the lock as USER xxx_FP.

The SELO-BF₂ electronics is the first safe electronics, for which the opening based on fingerprint is certified.

At least two opening codes shall be entered to open the safe using fingerprint (SELO-BF₂ and SELO-BFE₂). Another opening code must be entered in addition to fingerprint. This can be either another Fingerprint (SELO-BF₂ only), but also a pin code or an additional E-Key.

All the fingerprints are stored in the system with a value of 6/12 (corresponding to a half value). In order to acquire the authorization to open, a value of at least 1 must be achieved. A pin code with a value of at least 1/2 must be therefore entered for the opening, a value of 1 can be also achieved with an additional fingerprint.

Attention: The values can be adjusted only using additional software. When the programming is made on the safe faceplate, the pin code and the E-Key are automatically assigned the value of 1, the fingerprint receives the value of 1/2.

Attention: For security reasons as related to programming using the software, it is not allowed to communicate all the opening codes to a single user in case three opening codes are used (value A fingerprint is 1/2, value B 1/3, value C 1/3).

Example:

User A has defined his finger in the system as opening code (its value is 1/2). This user can be still authorized in the system with an additional opening code with a value of 1/3. A user B now needs an additional opening code with a value of at least 1/3. If a code and/or an E-Key should be additionally assigned to a user with fingerprint, it is to be created separately. Inversely, the fingerprint should be assigned separately to a user with a code and/or an E-Key*.

To enable the use of additional functions such as time switching or calendar functions, you need additional software. Then you will be able to use the overall user administration.

Attention: Should the user data in the safe electronics be administered using the software, the data must be stored on a removable data carrier. Their saving in a computer is not admissible, is identified by the system and not allowed. The removable data carrier should be stored at a safe place (e.g. a safe) after the programming.

In order to enhance the protection against intrusion, the following points should be observed:

For locking systems with material code carriers, e.g. an E-Key:

- **The code carrier should be consistently stored safely, so that it is accessible only to the authorized persons.**
- **In case of a loss of the code carrier, the lock should be immediately replaced or converted to a new combination by changing the coding, and/or the code of the lost code carrier should be blocked/deleted.**

For locking systems requiring a code:

- **No personal data (e.g. dates of birth) or other data, for which a link can be derived to the code owner, should be used for coding.**
- **If the code is stored in writing, such document should be consistently stored safely, so that it is accessible only to the authorized persons.**

Made in Germany

www.secu-gmbh.de

SELO-B₂
SELO-BF₂
SELO-BFE₂

• **Attention: Any changes of the administrator code and of the user codes shall be made with the safe door opened!**

• **When the locking system has been reset to another code, this new code should be repeatedly used with the safe door opened.**

1.1 Description of basic functions

You can program your lock based on the following description.

You can see the programming instructions on the display. To program the lock (enter into the menu), please press the "Function" key, when the symbol "M" is displayed. You can move within the menu using the keys "1" scroll up (symbol on display) and "2" scroll down (symbol on display). When the symbol "<" is displayed, you can use the "Function" key to skip to the next higher menu level, and choose a particular menu item using the "Enter/On" key.

The battery symbol indicates the current battery status:

■ : Battery full
[] ■ : Battery empty (please replace the batteries)

1.2 Description of programming and user mode

Please find the menu structure shown on the following pages. Also the navigation is indicated. Additionally, each of the menu items is clarified:

Code change menu

Change of the administrator and user codes

Language/Sprache menu

Language setup

E-Key synchronization menu

In this program, the channel of the E-Key is adapted to the channel of the input unit.

This function is necessary when the radio channel of an input unit is modified, although other radio keys (with the old channel setup) are still logged.

Info menu

Indication of version and serial number

SNA: Lock serial number

Administrator menu

This includes all the menus that can be used only with the administrator authorizations. They include:

- **Create User**

Users can be created here. A user has either a code, or an E-Key, or both. A separate user is always created for a fingerscan. Anatomically, there are people, the fingerprints of whom are not sufficiently articulated for the system.

- **Assign E-Key**

An E-Key can be additionally assigned to a selected user here.

- **Delete**

Users and E-Keys can be deleted here. When a user is deleted, also the code and the E-Key belonging to the user are deleted. When an E-Key is deleted, the user is retained. To delete a fingerscan, the corresponding user has to be deleted. To delete all the fingerscans, please use the "FS-Reset" function (see below). *

- **Time**

Entry of the time and calibration of the clock. The clock is automatically calibrated between two specific times. Exceptions are a replacement of batteries and the switchover from summer to winter time.

- **Date**

Entry of date

- **Radio Channel**

The radio channel can be set up here (12 channels to select from). This can be required when the radio channel is already used by another application, e.g. WLAN. In case of collision with WLAN systems, a space of three channels is recommended.

- **Priority:**

In case the door cannot be opened after several attempts with the E-Key, the priority of the door can be increased by this function. Inversely, also the priority of other door within the direct environment can be reduced.

- **Restructure:**

The use of this function is recommended when several users have been deleted.

- **Register:**

When either the lock unit or the keyboard is replaced, the two units are newly tuned to each other.

- **FS-Reset*:**

All the stored fingerprints are deleted, however, the corresponding users are retained. Please select this menu and follow the instructions on the display also in case of repeated error functions related to the use of fingerscans.

Made in Germany

www.secu-gmbh.de

SELO-B₂
SELO-BF₂
SELO-BFE₂

1.3 Detailed description of selected basic functions

1. Opening the safe using the factory code

- Press the On/Enter key
- The Code/Fingers** indication is displayed (**in case you possess electronics without fingerscan, Code is displayed instead).
- Enter the factory set code **123456**
- The instruction Please turn knob is displayed

Attention: The message Please turn knob implies the action with the knob of the locking unit, for which the opening code has been entered.

2. Changing the administrator code

- Press the On/Enter key
- The indication of Code/Fingers* is displayed
- Press the Function key
- The Change code menu is displayed
- Press the On/Enter key
- The indication of Administrator is displayed
- Press the On/Enter key
- The indication of the Old code is displayed
- Enter the factory set code **123456**
- Press the On/Enter key
- The indication of the New code is displayed
- Enter the new code
- Press the On/Enter key
- The indication of Repeat code is displayed
- Enter the new code
- Press the On/Enter key
- The indication of Code successfully changed is displayed

3. Creating a user with a code:

- Press the On/Enter key
- The indication of Code/Fingers** is displayed
- Press the Function key
- The Change code menu is displayed
- By pressing the key 2 reach the Administrator menu
- Press the On/Enter key
- Admin setup Create user is displayed
- Press the On/Enter key
- Create code is displayed
- Press the On/Enter key
- At this point you are asked to enter the admin. code (factory setting 123456)
- The indication of User 00x is displayed
- Please enter the user code and confirm it with ENTER
- Press the On/Enter key
- FS combination to be confirmed with ENTER*** is displayed
- Press the On/Enter key and accordingly the Function key
- After confirmation, Save with the On key is displayed.

*****If a user with a value of 1 (right to open alone) should be created, the message FS combination to be confirmed with ENTER must be followed by pressing the Function key. If the user should be assigned access in combination with a fingerscan only, this inquiry is to be confirmed with ENTER.**

4. Creating a user with an E-Key:

- Press the On/Enter key
- The indication of Code/Fingers** is displayed
- Press the Function key
- The Change code menu is displayed
- By pressing the key 2 reach the Administrator menu
- Press the On/Enter key
- Admin setup Create user is displayed
- Press the On/Enter key
- Create E-Key is displayed
- Press the On/Enter key
- At this point you are asked to enter the admin. code (factory setting 123456)
- FS combination to be confirmed with ENTER*** is displayed
- Press the On/Enter key and accordingly the Function key
- User 00x Store E-Key using ENTER is displayed
- Press the On/Enter key
- E-Key in Prog mode, continue with Enter is displayed
- Press the On/Enter key
- After confirmation, Save with the On key is displayed.

*****If a user with a value of 1 (right to open alone) should be created, the message FS combination to be confirmed with ENTER must be followed by pressing the Function key. If the user should be assigned access in combination with a fingerscan only, this inquiry is to be confirmed with ENTER.**

5. Storing a user with fingerprint*:

- Press the On/Enter key
- The indication of Code/Fingers** is displayed
- Press the Function key
- The Change code menu is displayed
- By pressing the key 2 reach the Administrator menu
- Press the On/Enter key
- Admin setup Create user is displayed
- Press the On/Enter key
- By pressing the key 2 reach the Create fingerscan menu
- Press the On/Enter key
- At this point you are asked to enter the admin. code (factory setting 123456)
- The indication of Create fingerscan is displayed
- The indication of Store finger is displayed
- This procedure is repeated several times
- After a successful entry the indication User xxx successfully created is displayed

Made in Germany

www.secu-gmbh.de

SELO-B₂
SELO-BF₂
SELO-BFE₂

Attention: When saving a fingerprint it is important that the finger is laid evenly and in a straight position over the sensor. Follow the instructions on the display. The finger is saved only when it can be read in an optimum quality.

6. Opening with fingerprint*:

- Press the On/Enter key
- The indication of Code/Fingerp is displayed
- Move the saved finger over the sensor
- Value not achieved is displayed
- The Code/Fingers indication is displayed
- At this point, enter an additional opening code (not Fingerprint with electronic SELO-BFE₂).
- The instruction Please turn knob is displayed

In case following message is displayed: Value not achieved , an additional opening code shall be entered. (When the programming is made using the software only. When programming using the safe electronics, the indication Please use rotating knob is displayed already when the second opening code has been entered.)

7. Deleting a finger*:

- Press the On/Enter key
- The indication of Code/Fingers** is displayed
- Press the Function key
- The Change code menu is displayed
- By pressing the key 2 reach the Administrator menu
- Press the On/Enter key
- Admin setup Create user is displayed
- By pressing the key 2 reach the Admin. setup Delete menu
- Press the On/Enter key
- Delete user is displayed
- Press the On/Enter key
- At this point you are asked to enter the admin. code (factory setting 123456)
- Now you have to select the appropriate user by pressing the keys 1 or 2
- Press the On/Enter key
- The indication of Delete data to be confirmed with the On key is displayed.
- Press the On/Enter key
- The indication of Data record deleted is displayed

Additional users can be deleted using the On/Enter key. By pressing the Function key, you can reach higher menu levels up to the code entry.


1.4 Error messages*

The following error messages are indicated when a finger is being saved or the safe opened:

Error message	Elimination of causes
too fast! please repeat	Move the finger more slowly over the sensor
too aslant! please repeat	Move the finger straight over the sensor be read
too short! please repeat	Move the finger over the sensor in a way allowing more surface area to
place to the center and repeat!	Place your finger centrally over the sensor

1.5 Menu structure

Made in Germany
www.secu-gmbh.de



SELO-B₂
SELO-BF₂
SELO-BFE₂

1.6 REPLACING THE BATTERIES

As soon as the symbol depicting the battery condition indicates „almost empty“, the operator is also warned **Please replace batteries! each time the lock is operated. We recommend you heed the advice and change the batteries! The lock can only be unblocked a further, approximately, 50 times. Please note that none of the number codes can be changed until a set of fresh batteries has been fitted. To change the batteries, lift off the cover of the battery compartment with the tip of a screwdriver. Fit three leak-proof, type Mignon LR6, AA, alkaline batteries, paying attention to the correct polarity. Dispose of the old batteries in accordance with anti-pollution legislation!**



Made in Germany

www.secu-gmbh.de

SELO-B₂
SELO-BF₂
SELO-BFE₂

SECU Sicherheitsprodukte GmbH

Wormgermühle

D – 58540 Meinerzhagen

Germany

www.secu-gmbh.de

mail@secu-gmbh.de

Irrtum und Änderungen vorbehalten

Omissions and changes reserved

Sous réserve de fautes d'erreurs et de modifications

BA SELO-B 2, SELO-BF 2 and SELO-BFE 2 MD 07/2011

©SECU Sicherheitsprodukte GmbH

SELO-B₂
SELO-BF₂
SELO-BFE₂